Important Note:

Non professionals please don't buy this module. This switch module must work with our remote control.

Packing List:

- 1 X 4-channel 12V IR Self-lock Switch module
- 1 X 5-key IR remote (no battery)

Product Introduction:

1 Working voltage: 12V DC

Remote control power supply: A CR2025 button battery

2 VIN+: Connect with. 12V + GND: Connect with. 12V -

CK=normally open, COM=common, CB=normally close, all of these three ports connect with output.

- 3 Module Dimension: 65*45*20mm, with four fixed 3mm-bolt holes
- 4 Module Type: IR remote module
- 5 Receiver Distance: 8m
- 6 Working Mode: Self-lock control (Press the button on remote, then relevant Channel of the relay module will work. press the button once again, then it will stop.)

How the remote work?

- 1 Press the CH1 button, LED1 lights on, 1st channel will work. Press the CH1 button again, LED1 lights off, 1st channel will stop working.
- 2 Press the CH2 button, LED2 lights on, 2nd channel will work. Press the CH2 button again, LED1 lights off, 2nd channel will stop working.
- 3 The same with 3rd and 4th channels are the same.
- 4 Press the power button once time, then the four channels on the module will be closed. Press the power button once more time, then the four channels on the module will be released.

Tips:

- 1 The receiver module must be matched with our remote, usually it does not work with other wireless remote.
- 2 The receiver module works with 250VAC-10A, 125VAC-10A, 30VDC-10A, 28VDC-10A Load, it works for most home appliances, garage and other machine

