

DC 12V 18CH Relay Remote Switch 18 Relay Receiver 18 Button Remote Transmitter Contact RX TX ASK Light Lamp Smart Home Wireless

Packing list:

- 1 x Receiver
- 1 x Transmitter (with Battery)

Receiver

Working Voltage : DC 12V
Quiescent Current : less than 8mA
Working Temperature: -20°C- +70°C
Receiving sensitivity: more than -105dBm
Working Frequency: 315MHZ
Output Type: Input DC12V Output 0V Switching Value use Relay NO COM NC
Relay: 10A Relay have better load less than 5A
Size:133mm*74mm*18mm

Working Mode:

- 1-----18CH Toggle use " 1 " Button to Learn
- 2-----18CH Momentary use " 2 " Button to Learn
- 3-----18CH Latched use "3" Button to Learn
- 4-----1-9CH Toggle,10-18CH Momentary use "4 " Button to Learn
- 5-----1CH Toggle , 2-18CH Momentary use " 5 " Button to Learn

Learning Code:

Input DC12V for the Receiver, Press the Learning Button on the Receiver ,LED Indicator ON ,Release it, then press the relative Transmitter Button, Receiver LED Indicator flash for 1 time, it mean learning is successful.

Clearing Code:

Input DC12V for the Receiver, press the learning button on the receiver and hold for about 8s until the Receiver LED indicator OFF, it mean the code have been cleared

the Receiver can keep 30 pcs different code transmitter

Transmitter

Working voltage: DC12V 23A Battery
Working Current: less than 25mA
Working Frequency:315MHZ
Transmitting Power:18mW

