

## WiFi Light Switch 2CH 7V 9V 12V 24V DC 10A Smart Home 433mhz Remote RF Interruptor Wireless for Home

### Packing List:

- 1 X 4 Way Switch
- 1 X RF Remote Transmitter (Build-in a battery)

### Item specifics

Item Type:Switches  
Switch Type:APP Control  
Certification:CE,CCC  
Features:wifi switch  
Model Number:wifi switch  
Woking voltage:12V  
Maximum load::10A  
Working temperature:0-60 centigrade  
Frequency:wifi  
Transmission Distance:As far as your phone be connected with internet  
Controlled methods:Smartphone APP + Manual Control  
Channel:2 Way / 2 Channel  
Phone operating system:IOS, Android  
Size:75\*55\*24mm

### Packing List:

- 1 X 2 Way 7-24V DC Wifi&RF Switch
- 1 X 433mhz remote transmitter (with battery)

### Introduction:

- 1 Working voltage: DC 7V-24V
- 2 Maximum load: 10A
- 3 Working temperature: 0-60 centigrade
- 4 Controlled method: Smartphone APP + Manual Control+433mhz RF Remote
- 5 Transmission way: WIFI
- 6 Transmission Distance: As far as your phone be connected with internet
- 7 Channels: 2 Way
- 8 Size: 75\*55\*24mm
- 9 Remote battery: A 23A/12V battery

### How to connect phone with switch?

- 1 Download and install the software of "eWeLink" from APP store or Google play store.
- 2 Follow "eWeLink" instructions to register an account on it.
- 3 Log in your account of "eWeLink".
- 4 Press any manual control button (S1,S2) for 5 seconds until you see the LED D3 light flash quickly, then release it. Now add device on mobile phone by eWeLink APP according its introduction.
- 5 Now you can use your phone to control the switch under 2G/3G/4G signal.
- 6 You can name your own device and control it only by yourself.
- 7 You can also share your device with your family or friends.

### How to learn 433mhz transmitter?

- 1 Press "learning button" until you see LED flash 1 time, release button, then CH1 learn.
- 2 Press "learning button" until you see LED flash 2 times, release button, then CH2 learn.

### How to set working mode?


Supply DC 7-24V power to the relay.

- 1: Press mode button until you see D5 flash 3 times, release button, now it is self-lock.
- 2: Press mode button until you see D5 flash 2 times, release button, now it is inter-lock.
- 3: Press mode button until you see D5 flash 1 time, release button, now it is momentary.


### What is the difference between working mode?

- 1 Self-lock: Press remote button A , receiver CH1 ON. press button A again, then receiver CH1 OFF
- 2 Inter-lock: Press remote button A , receiver CH1 ON, and receiver CH2,CH3,CH4 OFF.
- 3 Momentary: Keep pressing remote button A, receiver CH1 ON. release button A, then receiver CH1 OFF

## Connect High voltage device




## Connect low voltage device




## How to connect with phone?

- 1 keep switch and phone in the same wifi service;
- 2 Supply power to switch;
- 3 Keep pressing any button between S1 or S2 for 5 seconds;
- 4 The D3 light will flash quickly;
- 5 Connect your phone by APP "eWelink"



## How to learn 433mhz remote signal?

- 1 Press "learning button" until you see LED flash 1 time, release button, then CH1 learn.
- 2 Press "learning button" until you see LED flash 2 times, release button, then CH2 learn.



## How to set working mode?

Supply DC 7-24V power to the relay.

1: Press mode button until you see D5 flash 3 times, release button, now it is self-lock.

2: Press mode button until you see D5 flash 2 times, release button, now it is inter-lock.

3: Press mode button until you see D5 flash 1 time, release button, now it is momentary.

